

ATHENA_{LEVA}

Compliments, you have chosen a machine that's unique in its kind. Read carefully what is advised in the manual to "prepare" your "**Athena Leva**". You will realise how easy it is to make excellent coffees and creamy cappuccinos. As time will pass you will also realise how little maintenance it needs.

Victoria Arduino

ATHENA_{LEVA}



Model: Athena 2 Groups - Net weight: 60 Kg - Gross weight: 70 Kg - Thermal power: 3000 W - Boiler capacity 15,2 lt.
Dimensions: 640 x 550 x 710h mm - Packaging dimensions: 850 x 630 x 580h mm - Finishing in hammered sheet: copper, chrome, brass

Model: Athena 3 Groups - Net weight: 75 Kg - Gross weight: 85 Kg - Thermal power: 5000 W - Boiler capacity 22,8 lt.
Dimensions: 840 x 550 x 710h mm - Packaging dimensions: 1050 x 630 x 580h mm - Finishing in hammered sheet: copper, chrome, brass



The international marks of approval certify that all the machines have undergone very careful tests and inspections

GENERAL NOTES ON THE CONSIGNMENT

SAFETY DIRECTIONS

1 This manual is an integral and essential part of the product and it will have to be consigned to the user. Read carefully the directions stated in this manual as they supply important advice about the safety of the set up, of the use and the maintenance.

Keep this manual with care for any further consultations.

2 After having taken off the packaging, make sure about the machine's integrity. If in doubt, do not use it and ask to professionally qualified personnel. The packaging elements must not be left at children's reach as they are potential sources of danger, and be disposed of carefully.

DANGER OF POLLUTION

3 Before connecting the machine make sure that the data on the plate correspond to the electric supply net. The set up must be carried out respecting the actual regulations within the Country where the machine is set up, according to the manufacturer's instructions and by qualified personnel.

The manufacturer cannot be considered responsible for possible damages caused by the lack of grounding of the plant. For the electrical safety of this machine it is compulsory to arrange the plant of grounding, asking to a certified and qualified electrician to check that the electric power of the plant is suitable for the maximum power stated on the plate.

In particular he/she will also have to make sure that the section of the plant's cables is suitable for the power absorbed by the set.

It is forbidden to use adapters, multiple sockets and extensions.

If their use were crucial it is necessary to call a qualified electrician.

4 The machine has to be set up according to the local health regulations in being for the hydraulic plants. So for the hydraulic plant ask to an authorised technician.

5 This set must only be used in the way described in this manual.

The manufacturer cannot be considered responsible for possible damages caused by improper,

wrong or irrational uses.

⚠ WARNING

Before using the machine read the whole manual or at least the safety prescriptions and the getting ready.

⑥ The use of any electric set implies complying with some fundamental regulations. In particular:

- do not touch the set with wet hands or feet
 - do not use the set barefoot;
 - do not use extension in rooms with showers or baths;
 - do not pull the feeding cable to disconnect the set from the power supply net;
 - do not leave the set exposed to atmospheric agents (rain, sun etc.);
 - do not allow children to use the set, neither unauthorised personnel and anyone who hasn't read and completely understood this manual.
-

⑦ The authorised technician before performing any operation, has to unplug the machine after having switched off the switch.

⑦ **bis** For the cleansing operations, the machine has to be set on energetic state **"O"**, that is to say **"machine's switch switched off and "** and one has to strictly keep to what is foreseen in this manual.

⑧ In case of breakdown, fault or bad working, switch the set off. It is strictly forbidden to intervene. Ask only to professionally qualified personnel.

The possible fixing of the products will have to be carried out by the manufacturer or by an authorised assistance centre by using exclusively original spare parts.

Failing the respect of what is written above, the safety of the set can be compromised

⑨ At the set up, the certified electrician will have to foresee a unipolar switch as it is foreseen by the actual safety regulations with contacts' opening distance equal to or bigger than 3 mm.

⑩ To avoid dangerous overheating we suggest unrolling the power cable for its full length.

⑪ The user must not replace the power cable of this set. In case of damage, switch the set off and for its replacement ask only to professionally qualified personnel.

⑫ If you decide not to use this kind of set anymore, we suggest to make it ineffective after unplugging it, and to cut the power supply cable.

⚠ WARNING! DANGER OF POLLUTION

Dispose of the machine carefully: either ask to an

authorised centre for its disposal or get in touch with the manufacturer that will supply you with the necessary information about it.

13 To help the machine's aeration place it at cm 15 from the walls from other machines.

14 When using the steam pipe, pay attention not to put your hands under it and not to touch it soon after the use.

⚠ WARNING! DANGER OF BURNING

15 Remember that before any set up operations, maintenance, unloading, regulation, the qualified operator will have to wear gloves and shoes for accident-prevention.

⚠ WARNING

INFORMATION TO THE USERS




Under the senses of art. 13 of Law Decree 25th July 2005, n. 151 "Implementation of the Directives/ Guidelines 2002/95/CE, 2002/96/CE and 2003/108/CE, concerning the reduction of the use of dangerous substances in electric and electronic equipment, as well as the disposal of wastes".

The symbol of the crossed large rubbish container that is present on the machine points out that the product at the end of its life cycle must be collected separately from the other wastes. The user for this reason will have to give the equipment that got to its life cycle to the suitable separate waste collection centres of electronic and electrotechnical wastes, or to give it back to the seller or dealer when buying

a new equipment of equivalent type, in terms of one to one. The suitable separate waste collection for the following sending of the disused equipment to recycling, the dealing or handling and compatible environment disposal contributes to avoid possible negative effects on the environment and on the people's health and helps the recycling of the materials the machine is composed of. The user's illegal disposal of the product implies the application of administrative fines as stated in Law Decree n.22/1997" (article 50 and followings of the Law Decree n.22/1997)

DESCRIPTION OF MACHINE CONTROLS AND OPERATION



TRANSPORT AND MOVEMENT

MACHINE IDENTIFICATION

For any communication with the manufacturer Victoria Arduino, always quote the machine's number plate.

The machine is carried in pallett with other machines in cardboard boxes fastened to the pallett through centring or ropes.

Before carrying out any transport or movement operations, the operator will have to:

- wear gloves and shoes suitable for accident-prevention and an overall with elastic bands on the limbs.

The pallett transportation has to be carried out with a suitable lifting means (like a forklift truck).

⚠ WARNING! DANGER OF CRASH OR COMPRESSION

The operator during the movement, has always to pay attention that people, things or objects are not in the way in the operation's area.

Lift the pallett slowly at about 30 cm from the ground and reach the loading area. After checking that there are no obstacles, things nor people, proceed to the loading.

Once you get at destination, always using an adequate lifting means (e.g. forklift truck), after making sure there aren't things nor people in the unloading area, take the pallett to the ground and move it up to 30 cm from the ground, until the stocking area.

⚠ WARNING! DANGER OF CRASH OR COMPRESSION

Before performing the following operation,

check the load is safe at its place and that when cutting the centring or ropes it doesn't fall down. The operator wearing gloves and shoes for accident-prevention, will have to proceed to the cutting of the centring or ropes and to the stocking of the product. During this operation, please check the technical characteristics of the product to see the machine's weight to be stocked and be able to act consequently.

⚠ WARNING! DANGER OF POLLUTION

Once you have freed the machine from the pallett or the container, dispose of it carefully, danger of pollution.

SET-UP INSTRUCTIONS

After having checked that nothing fails in the packaging, put the machine in the place foreseen and pay attention that it is level by adjusting the pins. If the extension pins are foreseen, the assembling will be carried out by untwisting completely the pin and twisting it back again on the metal insert supplied with the extension, then put the cylindrical shell made of plastic on the insert.

Then twist the levers' arms that are on the respective supply groups.

Place the softener in the space foreseen. We remind that for the VICTORIA ARDUINO ATHENA LEVA does not have a pump, the pressure that is necessary for the coffee supply is gained by the lever group, so the connections' operations are quite simplified.

the pump is built-in the machine itself, so the fastening operations will be extremely simplified.

We advice to avoid narrowing in the tubes, to pay attention to the unloading and to use an electric cable of equal section, if the one supplied is not enough.

The machine must always be protected with an automatic switch of adequate power.

It is advisable to fit a pressure reducer between the machine and the water mains. This piece, which is supplied with the machine, serves to guarantee the correct pressure level of the water entering the machine. The inlet pressure for the coffee machine should be approximately 2 bar.


The Company is not responsible for any damage caused to things or people deriving from failing the safety regulations' observance.

STARTING

Even if all the machines VICTORIA ARDUINO have an automatic level, it's good rule, in the initial phase, to fill the boiler manually to avoid that the electric resistance is damaged and the electronic safety is connected (this one sticks the machine if the self-level is inserted more than 90 seconds. If this happens it is anyway enough to switch the machine off and then switch it on again, to complete the boiler's loading)

Removing the grill and the worktop drip tray it is possible to operate on the hydraulic circuit of the machine (see picture).

The entrance machine tap 1 must always be turned open after the connection to the machine's net has been carried out.



To carry out the manual filling, before switching the machine on, turn the manual loading tap 2 that is below the worktop.

Once the boiler is half filled, turn again the manual loading tap 2 and switch the machine on in order to activate the automatic level, also check that the water inlet cock 1 and the automatic level cock 3 are open.

Remark: a tap is turned open when turning the lever it is parallel to the tap's body.

After about 20 minutes the machine will have reached the working pressure that can be noticed and taken from the double scale manometer. To change the boiler working pressure, (and also its temperature) according to the different needs or characteristics of the coffee used, it is necessary to remove the cups warming band, the cups warming plate and the side right panel and to turn the manostat regulation screw, by turning it clockwise the pressure

decreases and vice versa (normally the machine that has been tested is adjusted at about 1-1.2 bar)

STEAM PIPE'S USE

To use the steam it is necessary to turn the steam tap anticlockwise: a steam's flux regulation is possible when coming out from the pipe.

When the steam comes out, do not touch the pipe with any of parts of your body nor put your hands under the pipe.

⚠ WARNING! DANGER OF BURNING

To get the cream when warming the milk, dip the steam pipe at the bottom of the container for its 3/4 (preferably in a truncated- conic shape). When the milk boils, move the steam pipe to the surface skimming the milk with small vertical movements to get the cream you

want. At the end of each operation, remember to clean carefully the steam pipe using a wet cloth.

USE OF HOT WATER

To use hot water it is enough to turn the hot water tap anticlockwise.

When hot water comes out, do not touch with the parts of your body nor put your hands under the pipe.

⚠ WARNING! DANGER OF BURNING

ESPRESSO COFFEE PREPARATION

Unfasten the filter holder from the group and put one or two quantities of grounded coffee according to the filter you are using; press the coffee using the appropriate small press supplied with the kit and before fastening the filter-holder to the group, clean the ring edge of the filter to take off possible coffee remains

that could also damage the perfect grip of the group and the filter-holder.

Then insert the filter-holder in the group, fastening it; push the lever down until its end of run. Wait some seconds for a possible pre-infusion of the coffee delivery. Start the lever's coming up and pay attention that your body does not obstruct the lever's way.

Only remove the filter holder when the lever has returned to its original position

BODY CLEANSING

To keep unchanged the machine's characteristics in time, you have to clean it quite often. Do not use any detergent product, use only a soft clean sponge and some water.

Possible body oxidation is normal, as it is made of brass or natural copper (according to the model).

FILTERS AND FILTER HOLDERS' CLEAN- SING

Add two teaspoons of detergent in half a litre boiling water and dip in the filters and the holders for about half an hour. Rinse carefully in fresh water.

Use glass or inox steel containers and keep the filter holder's handle outside the detergent liquids.