

Removing MAINTENANCE from the Mythos Grinder

1. Access programming by pressing the Star and Triangle buttons together, simultaneously.
2. Scroll through programming using the Star button until MAINTENANCE is on the display.
3. Use the Single Dose button to turn MAINTENANCE to ON.
4. Use the Star button to scroll to the next page, then press and hold the Double Dose button for a couple of seconds, until you hear a beep, to reset the internal maintenance dose counter.
5. Press and hold the Star button for about 5 seconds, until the machine returns to normal operation.
6. Access programming by pressing the Star and Triangle buttons together, simultaneously.
7. Scroll through programming using the Star button until MAINTENANCE is on the display.
8. Use the Single Dose button to turn MAINTENANCE to OFF.
9. Press and hold the Star button for about 5 seconds, until the machine returns to normal operation.